


Lees: Reverse Racking, Rheology and Recovery



Simon Nordestgaard
The Australian Wine Research Institute



- Background – the problem with wine movements
- Reverse racking – a different approach to lees removal
- Rheology – the science of material (e.g. lees) flow
- Recovery – new(ish) technologies for lees processing




Problems with wine movements

- Labour (setup, pushes, tank cleaning)
 - Water use / wastewater production
 - Tank availability
-
- Interested in practices and technologies that
 - allow wine to remain in the same tank, while still achieving the same processing outcome

Normal racking



The Australian Wine
Research Institute




Reverse racking



The Australian Wine
Research Institute


**Avoid having to move the bulk
of the wine and clean a tank**



Reverse racking




The Australian Wine
Research Institute



Reverse racking - challenges



The Australian Wine
Research Institute




The supernatant can channel through the lees, depending on:

- Lees rheology (i.e. flow characteristics)
- Tank design (e.g. floor angle), surface finish, and internal/external outlet sump/pipe work
- Pumping regime

Rheology basics (*rheo*: to flow)




The Australian Wine
Research Institute



Rheology basics – yield stress




The Australian Wine
Research Institute



Rheology – lees samples



The Australian Wine Research Institute



Notes:

Samples corresponding with bottom of tank, except gross red

Steady state reached at each shear rate at 20°C

Have only analysed one white ferment lees sample so far, getting more samples

Volume suspended solids (VSS): 3,000 x g, 5 minutes

Dry suspended solids (DSS): 70 °C, 24 hours (corrected for soluble solids using 0.2 μm filtered control)

Rheology – lees samples



The Australian Wine
Research Institute

Lees type	Yield stress (Pa)	App. viscosity @ 500s ⁻¹ (mPa.s)	VSS (v/v)	DSS (w/w)
Gross red	28	130	47%	16%
White ferment	<0.5	14	51%	15%
White juice	<0.5	6	27%	7%
White juice with bentonite	<0.5	5	31%	10%
Port with bentonite	3	13	60%	4%



Notes:

Samples corresponding at bottom of tank, except gross red

Have only analysed one white ferment lees sample so far, getting more samples

Rheological analysis at 20°C

Volume suspended solids (VSS): 3,000 x g, 5 minutes

Dry suspended solids (DSS): 70 °C, 24 hours (corrected for soluble solids using 0.2µm filtered control)

Temperature effects on rheology




The Australian Wine
Research Institute

Lees type	Yield stress (Pa)		App. viscosity @ 500s ⁻¹ (mPa.s)	
	20°C	4°C	20°C	4°C
Gross red	28	38	130	190
White juice	<0.5	<0.5	6	9

Settled white juice – example of gradients



The Australian Wine
Research Institute



Height (m)	VSS (v/v)	DSS (w/w)	App. viscosity @ 500s ⁻¹ (mPa.s)	d _{0.5} (μm)
10	n.m.	0%	1.9	n.m.
2.2	<2%	0%	2	11
1.7	<2%	0%	2.3	11
1.2	9%	0.3%	2.9	11
0.9	18%	3%	4.3	12
0.5	23%	5%	4.6	14
0	27%	7%	5.8	18

Notes:

Rheological analysis at 20°C

Volume suspended solids (VSS): 3,000 x g, 5 minutes


Dry suspended solids (DSS): 70 °C, 24 hours (corrected for soluble solids using 0.2μm filtered control)

Particles size by laser diffraction (Malvern Mastersizer 2000)

Oak chip effects on rheology



The Australian Wine
Research Institute



Lees layers	Yield stress (Pa)	VSS (v/v)	DSS (w/w)
Grape and yeast derived lees	60	60%	19%
Oak chips lees on tank bottom	280	n.m.	33%


- Oak chips provide structure to the lees and prevent it from flowing (high yield stress)
- Alternatives: 'oak-bomb' tanks, commercial liquid oak/tannins (regulatory issues?)

Recovery – RDVs (prevailing practice)



The Australian Wine
Research Institute

- RDVs have been the lees processing workhorse at wineries for many years
- Reasons that alternatives are being considered:
 - Quality downgrades for higher value products resulting from oxidation and dilution with water
 - Product can still be relatively turbid
 - High labour requirements
 - Filter aid (perlite or DE) needs to be purchased and spent material dealt with
 - Operator safety? Perlite seems to mainly be used instead of DE so appears to be much less inhalation risk than when working with DE (perlite contains <0.1% crystalline silica)



Pall Oenoflow HS



The Australian Wine
Research Institute


- Similar to standard cross-flow
- PVDF symmetric membrane
- Wide bore hollow fibres (~3mm?)
- Upwards rather than downwards flow (maybe helps prevent settling, clogging)
- Versatile – most types of lees & wine
- Rotary sieve to remove seeds, petioles, etc



Schematic (including rotary sieve)



Filter skid (cut-away of a filter module inset)



Flow path schematic

Bucher-Vaslin Flavy FX (adapted) & Leestar



The Australian Wine
Research Institute

1. Adaptation of normal Flavy FX wine X-flow to use on settled must lees (largest volume of lees)


- Must lees or wine (no fining agents allowed in either)
- PES asymmetric membrane
- Wide bore hollow fibres (3mm instead of 1.5mm)
- Rotary sieve to remove seeds, petioles, etc
- Head cleaning system to prevent blockages



Rotary sieve + filter + head-cleaning + wide bore

2. Leestar

- TiO_2 membrane on sintered SS support
- Very wide bore (18mm)
- Versatile – most types of lees (too slow for wine?)
- Requires cooling – a lot of heating? (low filtrate per recirculation)



Unit with flow schematic and internal config.

Della Toffola Omnia CFKF



The Australian Wine
Research Institute

- Ceramic membrane on titanium support
- Wide bores in filter monoliths (3.5 – 6mm)
- Versatile – most types of lees and wine
- Rotary brush strainer to remove seeds, petioles, etc
- Head cleaning system with brushes and aspirator



Filter unit (including rotary brush strainer on the right)



Filter monoliths in housing




Head cleaning system

TMCI Padovan Dynamos




The Australian Wine
Research Institute


- Cross-flow cleaning action on membrane generated by rotating filter as opposed to recirculation flow
- Ceramic membrane
- Versatile – most lees types (too slow for wine?)



*Ceramic rotary
filter discs*



Filter unit



Flow schematic


Decanter centrifuges (e.g. GEA Westfalia, Alfa-Laval)



The Australian Wine
Research Institute

- Separation principally by centrifugal force as opposed to by screening
 - Depends on a solid-liquid density difference
 - More effective at removing larger rather than smaller particles
- Lower cake moisture content and potentially higher throughput than lees cross-flow filters
- Turbid product relative to lees cross-flow filtration – additional filtration required
 - Is a pretreatment rather than a final clarification step
- One-pass as opposed to recirculating operation

$$v = \frac{d^2(\rho_s - \rho_l)r\omega^2}{18\mu}$$



RDV alternatives - summary



The Australian Wine
Research Institute

- Difficult to know which of the alternatives is best without controlled comparative trials on a range of different lees over a long period
- Lees filters described provide much clearer product than RDVs
- Equipment generally features increased level of automation over RDVs
- Lower wine recovery than RDV with some of the devices discussed, but lower turbidity and higher quality
- Very short payback periods (<2 years) are claimed by several suppliers – but payback period may be quite winery dependent, e.g.:
 - Labour use for RDVs at the winery? (is 1 person operating 1 or 5 RDVs)
 - Level of downgrade from RDV use at the winery? (e.g. \$20/L → \$1/L vs. \$1/L → \$1/L)
 - Perlite disposal arrangements

Thank you – any questions?



The Australian Wine
Research Institute



Acknowledgements

- Australian grape growers and winemakers and the Australian government for funding through the GWRDC



- Wineries who have given us access to data and allowed us to collect samples
- Equipment manufacturers who have supplied information on their equipment